

NOTE

- 1. ALL VALVE BOX PROTECTION IS TO REMAIN IN PLACE DURING CONSTRUCTION UNTIL AT LEAST 10 DAYS AFTER SODDING AND MUST BE COMPLETELY REMOVED AT FINAL APPROVAL WITH LID ADJUSTED TO GRADE LEVEL (GL).
- 2. PROTECTION TO BE APPLIED TO BOTH LINE VALVE BOXES AND HYDRANT BRANCH VALVES.
- 3. PROTECTION TO BE 150mmØ P.V.C. PIPE, BLUE IN COLOUR.
- 4. TRACER WIRE TO BE INCLUDED.
- 5. VALVE TO BE RESTRAINED AS SHOWN IN STD. 1-5-9.
- 6. ALL PIPING, FITTINGS, VALVES, APPURTENANCES AND MECHANICAL RESTRAINTS TO BE c/w DENSO PASTE, DENSO MASTIC AND DENSO TAPE OR APPROVED EQUAL, APPLIED TO MANUFACTURER'S RECOMMENDATIONS.

