

INDOOR Water Efficiency Kit

Installation Instructions

Displacement Bags

Fill the displacement bag with water and securely seal the top. Hang the bag in the tank, ensuring the bag does not interfere with the operation of the toilet tank. Check the displacement bag periodically to insure it remains in place and has not shifted after use.



Leak Detection Tablets

Place leak detection tablets in toilet tank and wait 1/2 an hour. Do not use the toilet during this time. If after 1/2 an hour colour has appeared in the toilet bowl, then a leak is present, if water remains clear, the toilet is not leaking.

Kitchen and Bathroom Faucet Aerator

Step 1. Turn off water to faucet. Place tape around faucet and old aerator to protect their finish and then unscrew clockwise (use a wrench if necessary).

Step 2. Turn water back on to rinse new aerator under water for a few seconds. Shut off the water once again and screw on the new aerator counter clockwise, tightening it by hand, avoiding cross-threading.

Step 3. If the faucet is threaded on the inside, stack the faucet washer and aerator washer on top of one another then screw aerator into place. If the faucet is threaded on the outside, remove the aerator washer and screw into place.

Step 4. Turn water back on to check for leaks. If there is a water leak, tighten the aerator in small increments – do not over tighten.



Low Flow Showerhead with on/off Trickle Device

Remove the existing showerhead from the shower arm. Before installing the new showerhead, turn on the water and let it run for several seconds to wash out the pipe. Turn water off and wrap the threaded end of the pipe clockwise with Teflon tape. Screw on the new showerhead and hand tighten, being careful not to cross-thread. Test the showerhead by running water, if it leaks, proceed to hand tighten until it fits snugly however do not over tighten.

