

OUTDOOR Water Efficiency Kit

Installation Instructions

Mechanical Water Timer

Disconnect garden hose from outdoor tap. Attach timer to outdoor tap by screwing copper end onto faucet. Attach garden hose to green end of timer. To set water flow, press down on black dial and select desired time by matching it up with the arrow, located on side of the timer.



Trigger Hose Nozzle

Unscrew present nozzle or sprinkler from outdoor garden hose. Attach trigger hose nozzle by winding it clockwise.



Hose Coupling Filter Washers

Remove existing nozzle trigger from garden hose. Place washers (round rubber rings) around filters (screens) and insert into hose ends. Place yellow coupling device over hose end and screw both pieces onto existing garden hose.

Hose Repair and Coupling-Mender

The yellow coupling hose repairs can be used in conjunction with the filter washers, or alone. To connect two pieces of hose, simply wind each hose piece into yellow coupler. The coupler acts as a joint to connect two pieces of hose to each other.



Rain Gauge

Insert rain gauge pointed end down in the lawn or in the garden, away from trees or anything that might obstruct rainfall. When the gauge reads one inch (2.5 cm), the lawn has been sufficiently watered and further watering via a garden hose is not necessary.

